

Getting Started

Commonwealth of Pennsylvania Department of Transportation

BRADD Software

INSTALLATION

The provided website download contains the following installation files for the licensed PennDOT BRADD software: the installation program (*Setup.exe*), installation and operation instructions (*Getting Started.pdf*), the software license agreement (*LicenseAgreement.pdf*), and other installation files.

BRADD is supported on Windows 10, and Windows 11 operating systems.

Before installing this version of BRADD, you must uninstall any other version of BRADD (Version 3.1.0.0 or later). In order to run two different versions of BRADD, you must use two different workstations/PCs.

Your company name and software serial number, found in the download e-mail, are required when installing the program, requesting future versions of the program (i.e., enhancements, modifications, or error corrections), and requesting program support. You may want to print the software license agreement (*LicenseAgreement.pdf*), record the company name and license number (first six digits of the serial number) in the spaces provided, and keep it in a safe place.

The following pages contain Chapter 4 of the BRADD User's Manual. The BRADD User's Manual, in its entirety, will be available once BRADD is installed successfully. Chapter 4 contains important installation information and should be read before beginning the installation.

Getting Started

This page is intentionally left blank.